

Albert Herring
Front Of House Focus Notes

#301

Sharp to shutter

Offstage cut to skirting board

Onstage cut up back on SR 1/3rd

US cut to edge of show deck or off full black

DS cut to 1' US of floor front

#302

Sharp to shutter

Offstage cut up back on SR 1/3rd

Onstage cut up back on SL 1/3rd

US cut to edge of show deck or off full black

DS cut to 1' US of floor front

#303

Sharp to shutter

Offstage cut to DS edge of set

Onstage cut up back on SL 1/3rd

US cut to edge of show deck or off full black

DS cut to 1' US of floor front

#306

Mirror #301

#307

Mirror #302

#308

Mirror #303

#311

As #301, offstage cut to 1 panel up from floor

#312

As #302

#313

As #303

#316

Mirror #311

#317

Mirror #312

#318

Mirror #313